






















Parts list

Item	#	Part.Nr.	
1	1	HN52254	 
	2	SL03061	
3	2	HN52257	
4	2	CN52259	  
5	4	GB95-85	
6	4	GB6182-86	
7	2	HN52263	 
8	2	CN52258	
9	1	HN52270	  
10	1	HN52274	
11	2	SN52251	
12	6	M8X45	   
13	2	M8	
14	6	M8	
15	6	GB T 845-ST4.2×16	
16	1 set	258703 CN65015	 


1




2



3



4



EXIT Toys
 Edisonstraat 83
 P.O. Box 369, 7000 AJ Doetinchem
 The Netherlands
 Tel. : +31 314 323 005
 Email : info@exittoys.com